

Outline: Getting an NMR Spectrum

- Prepare Sample: Deuterated Solvent in NMR Tube
- Adjust Sample Depth in Spinner, Insert
- Lock on Solvent Deuterium Peak
- Shim: Maximize Field Homogeneity
- Acquire FID Data (sum over multiple scans)
- Process NMR Data (Fourier Transform)